


# CLAMP

Note that over-tightening of clamp may deform tube, cause binding of actuator and void the warranty

---



## Heavy Duty Tube Mounting

- Position clamp onto tube.
- Tighten bolts uniformly to 125 in-lbs max. ***Do not over-tighten.*** Overtightening will deform actuator tube.

